




15




18




16



19



17





Hilti
LI-S
Tel.
Fax
www

Hilti =
Right

HILTI

Hilti Corporation
494 Schaan
: +423 / 234 21 11
: +423 / 234 29 65
w.hilti.com



HILTI

DD 350 / DD 500






HILTI










DD 350 / DD 500


Bedienungsanleitung	de
Operating instructions	en
Mode d'emploi	fr
Istruzioni d'uso	it
Gebruiksaanwijzing	nl
Manual de instruções	pt
Manual de instrucciones	es
Brugsanvisning	da
Käyttöohje	fi
Bruksanvisning	no
Bruksanvisning	sv
Οδηγίες χρήσεως	el
Ръководство за обслужване	bg
Upute za uporabu	hr
Instrukcja obsługi	pl
Инструкция по эксплуатации	ru
Návod na obsluhu	sk
Navodila za uporabo	sl
Návod k obsluze	cs
Használati utasítás	hu
Kasutusjuhend	et
Lietošanas pamācība	lv
Istrukcija	lt
操作説明書	zh
取扱説明書	ja
사용설명서	ko









9




10




11



12



13



14

